



NOTES:

1. CAST IRON COVER TO BE STAMPED "WATER" FOR WATERLINE VALVES, "REUSE" FOR REUSELINE VALVES, AND "SEWER" FOR FORCEMAIN VALVES
2. INSTALL NON-METALLIC TAPE APPROXIMATELY 24" ABOVE PIPE
3. DEBRIS CAP MUST BE INSTALLED AT TOP OF VALVE BOX.
4. TRENCH ADAPTOR MAY BE INSTALLED IN PLACE OF VALVE BOX AND DEBRIS CAP. SEE SECTION 2660.
5. NO VALVE SHALL BE INSTALLED IN CONCRETE FINISHED SURFACE OR IN SIDEWALK.

**TOWN OF BRASELTON WATER & SEWER DEPARTMENTS**

JOB TITLE  STANDARD DETAIL	SHEET TITLE  <b>VALVE BOX</b>	DRN. BY: EMI	REV. NO.	BY	DATE
		CKD BY:	A	EMI	05/01/18
		APPD. BY:			
		DATE: MARCH 2004			
		DETAIL No. W-8	FILE No. 03033W-8.dwg	SCALE: N.T.S.	